☞Please note that the logo may not always be centered with handle.

Actual size (100%)

■ = white

FRONT

